



NOTES:

1. CENTER BOXES OVER VALVES.
2. SET BOXES IN CROUND COVER/SHRUB AREA WHERE POSSIBLE.
3. SET BOXES PARALLEL TO EACH OTHER AND PERPENDICULR TO EDGE OF HARDSCAPE