



NOTES:

1. INSTALL SPRINKLER AT FINISHED GRADE
2. ALL PVC THREADS TO HAVE TEFLON TAPE