



NOTES:

USE TEFLON TAPE OR TEFLON PASTE ON ALL THREADED FITTINGS--SEE SPECIFICATIONS