



NOTES:

1. LOCATE AN AIR-RELIEF VALVE AT THE HIGH POINT OF EACH SYSTEM WITHIN A PLASTIC VALVE BOX, SEE DTL 26.
2. DRIPLINES TO BE LAID FLAT AND SECURED TO SUBGRADE WITH STAPLES AT 5' CENTERS PRIOR TO BACKFILL OR MULCH COVER.
3. USE CAUTION WHEN SECURING DRIPLINE WITH STAPLES. DRIPLINE SHALL NOT BE OBSTRUCTED OR KINKED.
4. REFER TO SPECIFICATIONS AND PLAN SHEETS FOR MORE INFORMATION.
5. INCLUDE OPERATION FLAG/PRESSURE INDICATOR STAKE FOR EACH INLINE DRIP ZONE.
6. PLANTS SHALL BE PLANTED BETWEEN DRIPLINES, NOT OVER LINES. CONTRACTOR TO MARK LOCATIONS AND REVIEW WITH UNIVERSITY'S REP. PRIOR TO PLANTING.