



**NOTES:**

1. INSTALL SPRINKLER AT FINISHED SOIL GRADE
2. ALL PVC THREADS TO HAVE TEFLON TAPE

