



**NOTES:**  
 USE TEFLON TAPE OR TEFLON PASTE ON ALL THREADED FITTINGS