



NOTES:
 USE TEFLON TAPE OR TEFLON PASTE ON ALL THREADED FITTINGS